



Specter Off-Road, Inc.  
21600 Nordhoff Street, Chatsworth, CA 91311,  
SOR@SOR.COM - (818) 882-1238  
E-Mail: sor@sor.com

---

## **SOR REPRODUCTION FJ55 GLOVE BOX PAD**

### **Part #172-06G-R**

1. Remove glove box door and hinge from dash. Retain hardware for re-installation.
2. Remove handle from door assembly, save original hardware for re-installation on new pad.
3. Remove old pad from metal plate and hinge.
4. Enlarge hinge holes slightly to fit new bolts included with kit.
5. Place metal backing plate and hinge onto pad. Install 3 new mounting bolts and lightly finger tighten. Check alignment of back plate and using a scribe or awl, puncture 1/8" deep holes in for mounting screws in the corners of the plate.
6. Screw plate to pad using provided screws. **CAUTION: Do not overtighten the corner screws! Tighten the 3 hinge mount bolts.**
7. Reattach handle to new pad with original hardware.
8. Reinstall glove box door assembly on dash

172-06G-R\_090717AS.INDD