



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#246-25-B TUBE BAR WRAP INSTALLATION INSTRUCTIONS

STEP 1. Due to curves it is best to actually lay the tube bar wrap on the bar you are going to cover, rather than measuring with a ruler or tape measure.

STEP 2. If you need to cut the material, BE SURE to seal the stitch locations with clear silicone or glue.

STEP 3. Wrap the material around the bar and secure the hook (rough side) to the wrap.

STEP 4. Due to weather changes, periodically check the tension on the wrap.

PLEASE NOTE

This tube bar wrap is not safety padding or safety protection.

The life expectancy and color intensity of this product depends on weather conditions and other factors regarding the use and treatment of the material.

CLEANING INSTRUCTIONS

Your new tube bar wrap can be cleaned with a mild soap, in cold water.

Allow to air dry over a chair, curtain rod, fence, etc. DO NOT put in a dryer.