



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238
E-Mail: sor@sor.com Internet: <http://www.sor.com>

#272-80 SUMMER EXTREME

Included with your new Summer extreme top are qty 2 footman loops and qty 4 #8 X 1/2" oval head phillips head screws. The footman loops and screws are used if you DO NOT have seat belt retractors mounted on the roll bar, near the bottom on each side.

FOOTMAN LOOP INSTALLATION

Center a footman loop behind the roll bar on each side. Mark the location of the holes, center punch and drill two 5/32" holes. Secure each footman loop with two #8 X 1/2" phillips screws.

SUMMER EXTREME INSTALLATION

1. Snugly fit the plastic strip sewn on the front edge of the cover into the metal channel above the windshield.
2. Position the cover over the roll bar.
3. Position the bottom webbing strap on each side through the footman loop OR around the seat belt retractor and thread back through the plastic buckle sewn on the bottom edge of the cover.
4. After the tension on the bottom webbing strap on each side has been properly adjusted, position the remaining webbing strap on each side around the roll bar and thread through the plastic buckle sewn on the cover.
5. Check the tension on the webbing straps and MAKE SURE the plastic sewn on the front edge of the cover is properly installed in the channel above the windshield.

Periodically check the tension on the straps and be sure the plastic is snug in the channel.

REAR WINDOW FLAP

Tightly roll the flap down and snugly mate the hook and loop pieces on each side.

CLEANING INSTRUCTIONS

Use any product, solution or agent that is compatible with vinyl.