



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#273-100 FIBERGLASS HALF DOORS

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: 12mm Socket, Electric Drill, 9mm Drill Bit, 10mm Combo Wrench, 12mm Combo Wrench, Phillips Screwdriver

INSTALLATION INSTRUCTIONS

- STEP 1: Install door regulators & outer door handles into fiberglass half door, use supplied screws for regulators.
- STEP 2: Leave door striker on body.
- STEP 3: Remove hard door from vehicle, leaving door hinges intact.
- STEP 4: Set fiberglass door in door opening, latching door regulator to striker.
- STEP 5: Line up door to body opening and mark hinges on door using hinges as template.
- STEP 6: Drill quantity 6, 9mm holes in door, carefully as to not puncture inside of door.
- STEP 7: Bolt doors to hinges with bolts, nuts and washers.
- STEP 8: Check alignment of door and tighten.

Top View Right Door

