



21600 NORDHOFF ST.  
CHATSWORTH, CALIFORNIA 91311 USA  
PH: (818) 882-1238  
E-Mail: sor@sor.com  
Internet: http://www.sor.com

## #284-30 ProComp Steering Stabilizer

### Installation Instructions

Please read all instruction from start to finish before you begin installation

1. Turn the steering wheel so the tires are in the straight position.
2. Install bracket A on the axle using the U-bolts and nuts provided. **NOTE: Depending on your vehicle, you may install the bracket in either position as per the illustrations below.**
3. Install the large diameter end onto the bracket A as per the illustration.
4. Install bracket B onto the cylinder rod stud as per illustration.
5. Pull the cylinder rod out half of its travel length and attach bracket B to the tie rod using the U-bolts supplied with your kit. **NOTE: Cylinder rod end should be slightly higher than the cylinder end.**
6. Turn the steering wheel fully right and fully left being sure there is not interference or binding
7. double check all nuts and bolts for tightness periodically
8. Omit bracket A on Toyota 4X4 Pick-ups. Use the stock axle mount.

