



21600 NORDHOFF ST.  
CHATSWORTH, CALIFORNIA 91311 USA  
PH: (818) 882-1238  
E-Mail: sor@sor.com  
Internet: http://www.sor.com

# SHACKLE INSTALLATION

## #287-41A-KIT, #287-41B-KIT, #287-41C-KIT

The Anti-Inversion Tri-Shackles should be installed as follows:

- The center part of each shackle should face inward on each end of the vehicle.
- The short end should be at the top, attached to the frame.

**Muffler and/or exhaust modifications may be required.**

**On the 2" lift kit, caster shims are not required. Disregard the installation instructions for these.**

