



21600 NORDHOFF ST.  
CHATSWORTH, CALIFORNIA 91311 USA  
PH: (818) 882-1238  
E-Mail: sor@sor.com  
Internet: http://www.sor.com

## SHACKLE INSTALLATION

### #288-70, #288-73, #288-74, #288-75 & #288-76

The Anti-Inversion Tri-Shackles should be installed as follows:

- The center part of each shackle should face inward on each end of the vehicle.
- The short end should be at the top, attached to the frame.

**Muffler and/or exhaust modifications may be required.**

