



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238, E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#309-4070-T FRONT TUFF DUCK SLIP COVER

FITS 1964-1971 FJ40

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Warm up slip covers in the sun till they are soft and warm before installation. Or you can put slip cover inside pillow case and put in clothes dryer for a few minutes. Be careful to close slip cover so the slip covers do not come in contact with the dryer drum, other wise you will melt the backing on this slip cover.

Be sure the hook and loop strips sewn along the sides of the cushions are separated. When properly installed, the tags on the backseat pockets should be facing each other.

INSTALLATION INSTRUCTIONS

- STEP 1. Position the driver's cover over the backrest, fitting the flap with three loop strips sewn on into the opening between the bottom of the backrest and top of the cushion. Be sure the flap goes all the way through to the back.
- STEP 2. Position the cover over the cushion. Align the strap on each side around the back of the metal support bracket and mate with the loop strip sewn on the flap.
- STEP 3. Position the long strap on the front, bottom of the cushion UNDER the seat and mate the hook strip on the strap with the loop strip on the flap.
- STEP 4. Position the passengers cover over the backrest, fitting the flap with two loop strips sewn on AND the long strap between the bottom of the backrest and top of the cushion.
- STEP 5. Position the cover over the cushion. Align the strap on each side around the back of the metal support bracket and mate with the loop strip sewn on the flap.
- STEP 6. Position the longer center strap AROUND the rear metal support, mating the hook and loop strips on the strap to each other.
- STEP 7. Position the two loop strips on the front, bottom of the cushion AROUND the metal supports and mate to the hook strips on the cover.
- STEP 8. Tilt the backrest forward. Position the loop strip on each rear, bottom corner of the backrest AROUND the metal support and mate with the hook strip sewn on the cover.

CARE INSTRUCTIONS

Cold water wash, line dry. May be dry cleaned, no Trichlorethylene.

NOTE: If covers are left in direct sunlight for extended periods of time covers will tend to fade.