



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238, E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#309-4610-T REAR TUFF DUCK SLIP COVER

**FITS 1976-1984 FJ40/BJ NON USA MODELS WITH
ANGLE CUT SEATS-NO ROLL BAR- WITH ARM REST**

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Warm up slip covers in the sun till they are soft and warm before installation. Or you can put slip cover inside pillow case and put in clothes dryer for a few minutes. Be careful to close the pillow case so the slip covers do not come in contact with the dryer drum, other wise you will melt the backing on this slip cover.

Be sure the hook and loop strips sewn on the underside of each cover are separated. On the underside of each cover there is a tag with a B or a C on it. B is the backrest (smaller cover) and C is the cushion (larger cover).

PLEASE NOTE: On the top of each backrest cover there is a cutout for the seat strap and on the underside of each cushion cover there is a cutout for the twist turn. When installing the covers, be sure the seat strap is positioned through the cutout and the twist turn also goes through the cutout. The cushion covers are designed to fit OVER the rubber bumpers on the underside of the seats.

INSTALLATION INSTRUCTIONS

- STEP 1.** Snugly fit a cover over each backrest. NOTE: The hook strip (rough surface) should be at the back and the loop strip (soft surface) should be facing you at the bottom of the cover. You might have to squeeze the backrest slightly to get the cover over the top and bottom corners.
- STEP 2.** Fold the hook and loop flaps around the bottom of the backrest and securely mate.
- STEP 3.** Bring the cushions to the UP position. Snugly fit a cover over each cushion. NOTE: The loop strip should go over the top of the cushion, while the hook strip will be wrapping around from the bottom. The cover must be positioned between the metal frame and over the cushion in each corner again. Like STEP 1, you might have to squeeze the cushions for proper position.
- STEP 4.** Fold the hook and loop flaps around the bottom of the cushion and securely mate.

After a few days of normal use, the covers will conform to the contour of your seats.

CARE INSTRUCTIONS

Cold water wash, line dry. May be dry cleaned, no trichlorethylene.

NOTE: If covers are left in direct sunlight for extended periods of time covers will tend to fade.