



21600 Nordhoff Street, Chatsworth, California 91311, USA
www.sor.com • (818) 882-1238 • sor@sor.com

80 SERIES TUFF DUCK SLIP COVER SET

**#309-801-#SET Fits 8/62-1/98 80 Series with
Leather Interior**

Front Covers

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Warm up slip covers in the sun till they are soft and warm before installation. Or you can put slip cover inside pillow case and put in clothes dryer for a few minutes. Be careful to close slip cover so the slip covers do not come in contact with the dryer drum, other wise you will melt the backing on this slip cover.

Be sure the hook and loop strips sewn on the underside of the headrest covers and along the back and sides of the cushions are separated. When properly installed, the tags on the backseat pockets should be facing each other.

INSTALLATION INSTRUCTIONS

- STEP 1. Remove the headrests from the backrests.
- STEP 2. Snugly fit the cover over the backrest and the cushion.
- STEP 3. Fit the three flaps, one on each side and one in the center, into the opening between the top of the cushion and bottom of the backrest. Be sure the three flaps go through to the back.
- STEP 4. Stretch the bottom side pieces back and mate the hook strips with the loop strips on the corresponding flap.
- STEP 5. Mate the hook strip on the center flap with the loop strip on the **UNDERSIDE** of the pocket.
- STEP 6. Reinstall the headrests and secure in the upper, first latch position.
- STEP 7. Fit a cover over each headrest. Mate the hook and loop strips on the underside.

After a few days of normal use, the covers will conform to the contour of your seats.

CARE INSTRUCTIONS

Cold water wash, line dry. May be dry cleaned, no trichlorethylene.

NOTE: if covers are left in direct sunlight for extended periods of time covers will tend to fade.

Passenger Covers

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Warm up slip covers in the sun till they are soft and warm before installation. Or you can put slip cover inside pillow case and put in clothes dryer for a few minutes. Be careful to close slip cover so the slip covers do not come in contact with the dryer drum, other wise you will melt the backing on this slip cover.

Be sure the hook and loop strips sewn on the underside of the headrest covers and along the back and sides of the cushions are separated. When properly installed, the tags on the backseat pockets should be facing each other.

INSTALLATION INSTRUCTIONS

- STEP 1. Remove the headrests from the backrests.
- STEP 2. Snugly fit the cover over the backrest and the cushion fitting the seat belts through the holes provided in the cover.
- STEP 3. Tilt the backrest & cushion forward. Fit the flap with two loop strips sewn on into the opening between the top of the cushion and bottom of the backrest. Be sure the flap goes through to the back.
- STEP 4. Stretch the bottom side pieces back and mate the hook strips with the loop strips on the center flap.
- STEP 5. Return the BACKREST to the locked, upright position. Position the strap around the bottom of the backrest latch release housing and mate to the hook strip on the UNDERSIDE of the backrest, next to the pocket.
- STEP 6. Return the cushion to the down, locked position. Reinstall the headrests and secure in the upper, first latch position.
- STEP 7. Fit a cover over each headrest. Mate the hook and loop strips on the underside.

CARE INSTRUCTIONS

Cold water wash, line dry. May be dry cleaned, no trichlorethylene.

NOTE: if covers are left in direct sunlight for extended periods of time covers will tend to fade.