



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238, E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#309-834-TR REAR TUFF DUCK SLIP COVER FITS 1/98 - 2007 100 SERIES

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Warm up slip covers in the sun till they are soft and warm before installation. Or you can put slip cover inside pillow case and put in clothes dryer for a few minutes. Be careful to close slip cover so the slip covers do not come in contact with the dryer drum, other wise you will melt the backing on this slip cover.

Be sure to hook the loop strips sewn on the underside of the headrest covers, along the back and sides of the cushions are separated. When properly installed, the tags on the back seat pockets should be facing each other.

INSTALLATION INSTRUCTIONS

- STEP 1. With the backrest in the upright position, remove the headrests.
- STEP 2. Position the cover over the backrest, folding the flap on the bottom around the underside. Be sure the holes for the headrest and rubber bumper are properly aligned.
- STEP 3. Securely mate the hook strip on the flap with the loop strip on the bottom, underside of the backrest. Mate the hook and loop strips around the release lever on the side panel of the seat. Mate the hook and loop on the front side of the flaps.
- STEP 4. Position the cover over the cushion, fitting the handle at the back through the cutout.
- STEP 5. Pull the side pieces back and securely mate each hook strip with the corresponding loop strip on the back.
- STEP 6. Reinstall the headrest and secure in the upper, first latch position.
- STEP 7. Fit a cover over each headrest. Mate the hook and loop strips on the underside.

After a few days of normal use, the covers will conform to the contour of your seats.

CARE INSTRUCTIONS

Cold water wash, line dry. May be dry cleaned, no Trichlorethylene.

NOTE: If covers are left in direct sunlight for extended periods of time covers will tend to fade.