



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238, E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#310-72 DELUXE SEAT COVERS INSTALLATION INSTRUCTIONS

GENERAL INFORMATION

It is highly recommended a professional upholsterer install these seat covers.

Installation should be done in a warm, dry location, above 70 degrees Fahrenheit. Allow the covers to sit in the sun or under a light to become more pliable before installation.

The fit of your new seat covers will be determined by the condition of your foam. In some cases it will be necessary to replace the foam. Replacement automotive rated foam can be purchased from SPECTER OFF-ROAD or through your local upholstery/trim shops.

The covers can be cleaned with any product that is compatible with vinyl.

Remove the seats from the vehicle. Unbolt the backrests from the cushions and remove all brackets. KEEP all the bolts, screws and washers.

DRIVER & PASSENGER CUSHION INSTALLATION

STEP 1. Remove the old covers.

STEP 2. Center the new covers over the seat, fitting the legs around the cutouts and the tie strings UNDER the legs.

STEP 3. Pull the tie strings snug and tie into a knot.

STEP 4. Reinstall the screws and washers through the vinyl into the original holes.

DRIVER & PASSENGER BACKREST INSTALLATION

STEP 1. Remove the old covers.

STEP 2. Center the new cover over the backrest and around the inside edges.

STEP 3. Secure the vinyl in place by snugly fitting the seat cushion clips around the vinyl and INSIDE EDGES of the backrest frame.

STEP 4. Align the panel on the back, making sure the vinyl remains on the inside. Reinstall the screws and washers into their original holes. DO NOT tighten completely at this time.

STEP 5. Starting at the bottom, set the welt strip UNDER the panel, making sure only the large round portion of the welt is showing. Tighten the screws as you go around. Trim off extra welt.

STEP 6. Bolt the backrests and cushions together and reinstall in your vehicle.