



21600 Nordhoff Street, Chatsworth, CA 91311 PH:
(818) 882-1238, E-Mail: sor@sor.com
Internet: <http://www.sor.com>

INSTALLATION INSTRUCTIONS

#345-401, 402, 403, 450, 125 & 126

SPECTER OFF-ROAD FRONT TUFF LINER MATS

1. Tuff liner mats are marked for your application. Carefully cut with a utility knife or exacto knife start from the pre-punched hole and cut carefully along the lines.
2. Applications that require opening a hole for the transmission and tranfercase shift levers, start with a smaller hole than pattern shows. You can adjust the hole larger for your desired opening.

**#340-104, #345-410, #345-460 40 Series Rear &
#345-611 & #345-612 Front & Passenger 60 Series**

SPECTER OFF-ROAD TUFF LINER

1. Applications for models who have a rear heater, the pattern is marked and the opening can be easily cut with a utility knife or exacto knife. Or you can bolt the heater on top of mat.

