



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#126-44, #126-44-A, #126-45, #126-45-A

Paying attention to two things when installing outer door handles will help to reduce the possibility of braking them. When inside the door, lubricate the pivot mechanisms with grease. Second, the adjustment of the outer door handle to the door regulator mechanism is critical in trying to keep from braking the handle at the hinge area. If your door handle opens the door at the beginning of the pull, or as you pull OUTWARD, the handle should last. If your door handle opens the door at the end of the pull, or as you pull UPWARD, this will cause the handle to break due to stress caused by the angle at the hinge point.